



### Vibro level indicator

Level limit switches for bulk goods

# **VF1.A3**

## **Appliance information**

Rhombus vibration rod Rhombus vibration rod robust single rod compact and versatile

Index	Page
Application   Construction   Characteristics   Function	02
Technical data   Electrical data	02
Versions / Dimensions	03
Dimensions - separate round-housing   Electrical connection	04
High alarm sensor   Low alarm sensor	05
Possibilities for installation   Protection against heavy load	06
Maximum load for vibration rod   Protection against bulk solids crashing down u	pon the rod . 06

M©LLET accurate point level

**ATEX** option

B1 Dust (Ex) II 1/2D Ex ta/tb IIIC T95 °C Da/Db

**ATEX** option

B3 Dust (Ex) II 1/3D Ex ta/tc IIIC T95 °C Da/Do



#### Application (intended use)

The MOLOSvibro of the VF1.A3 series is intended for the use as

level limit switch


in silos and vessels.

For all bulk solids with a minimum density of

0.01 t/m<sup>3</sup>.

For application in all industry sectors.

#### Construction



#### Characteristics

- Very robust vibration rod in Rhombus shape
- High sensitivity for bulk solids with a minimum density of 10 g/l
- Interface measurement possible
- Patented, braced membrane
- No digging free within the bulk solids due to small vibration amplitude
- Adjustable sensitivity in three setting adjustments: A for light, B for normal and C for sticking bulk solids
- High level and low level alarm selectable

#### **Function**

- Oscillation of the Rhombus vibration rod with a resonance frequency of approx. 285 Hz is stimulated by the electronic.
- As soon as the vibration rod has been covered by bulk solids, the oscillation will be damped.
- The electronic detects the damping and switches the relay signal.
- If the filling level sinks below the vibration rod, the rod starts vibrating with its resonance frequency again and the relay switches back.

#### **Technical data**

Material Round-housing Aluminium, RAL7001 Process connection and probe Stainless steel 1.4301 / 304 Rhombus vibration rod Stainless steel 1.4301 / 304 Suspension cable sheath Polyurethane

**Process connection** R11/2 EN 10226 or N3 11/2" NPT

-40 °C ... +70 °C Ambient temperature -40 °C ... +80 °C with separate housing

Process temperature VF12, VF13 -40 °C ... +80 °C -40 °C ... +70 °C

T(Process) VF12, VF13 high temperature E1 -15 °C ... +150 °C

E2 -20 °C ... +200 °C -20 °C ... +250 °C F3

Ta

p(Process) -0.95 bar ... 10 bar Process pressure

Minimum density of bulk solids 0.01 kg/l (t/m3)

for damping 1 second for start oscillation 2 to 5 seconds

Gland 2xM20x1.5 Cable entry

IP66/IP67 acc. DIN EN 60529 Type of protection with separate round-housing IP65 acc. DIN EN 60529

Maintenance none

Maximum load for the end 1000 N vertical (V)

of the vibration rod 250 N horizontal (H) Maximum tensile force at

2000 N suspension cable of type VF15 Installation position VF12, VF13 any vertical

#### Electrical data

Response delay

Supply voltage C8 20 ... 250 V AC / DC supply Power consumption  $\leq$  3 VA / 3 W Signal relay two potential free change-over contacts

Capacity of contact 8 A / 250 V AC 192 / 72 W at 24 / 48 V DC

Supply voltage C5 24 V DC ±10%  $\leq$  1 W (without load) Supply Power consumption potential free NPN / PNP Signal output


maximum 20 W switching capacity Capacity of contact maximum 350 mA constant current






#### **Versions/Dimensions**


#### VF12 Compact sensor




#### VF13 Rod extension sensor



#### VF15 Suspension cable sensor



E1 ... E3 High temperature







#### **Dimensions**

#### A33 Separate round-housing

#### Front and side views



With the separate round-housing the electronic will be mounted remote from the probe.



#### **Application**

- In vessels with heavy vibrations
- Process temperatures of 150 °C to 250 °C only in combination with lead-through housing in hightemperature design
- Ambient temperatures up to +80 °C in close proximity to the container wall.


#### Separate round-housing combinable with:

A33 lead-through housing at the probe

Metal protection tube with 2 m length. Different length on request.

#### **Electrical connection**


Wide range electronic C8



004-0210.CDR

#### **Electrical connection**

DC voltage electronic C5




# Vibro level indicator VF1.A3



#### High alarm sensor FH (factory setting)

**MOLOSvibro** level indicator of the **VF1**. series are configurated for **high level alarm** in the factory setting. The function can be changed with a jumper on the electronic board. The switching status is indicated by a LED on the electronic board, like it is explained below.

Free status - vibration rod oscillates freely



Electronic type
LED dispaly


C8

Switching status

NC C NO NO C NC Relay energized

Transistor conductive

High alarm - vibration rod covered with bulk solids



Electronic type LED dispaly

Switching status

**C8 ₩** 

C5

LED blinking

LED blinking


NC C NO NO C NC Relay de-energized

Transistor blocks

#### Low alarm sensor FL (jumper repositioned)

**MOLOSvibro** level indicator of the **VF1**. series can be used for **low level alarm** with a changed factory setting. The function can be changed with a jumper on the electronic board. The switching status is indicated by a LED on the electronic board, like it is explained below.

Covered status - Vibration rod covered with bulk solids



Electronic type

LED dispaly

**C8** ♠

₹<u>`</u>

LED on

\_\_\_ .


LED on

Switching status

NC C NO NO C NC
Relay energized

Transistor conductive

Low alarm - Vibration rod oscillates freely



Electronic type

LED dispaly

C8
LED blinking

C5

LED blinking

Switching status




Transistor blocks

004-0251




#### **Possibilities for installation**




### **Protection against heavy load**

If needed, a protection roof or a stable deflector has to be installed inside the container, in order to protect the probe and the rod against impinging bulk solids.

Between protection roof and the probe has to be enough space that bulk solids could penetrate but not jam.





#### **Maximum load for vibration rod**



### Protection against bulk solids crashing down upon the rod

Level indicators must not be affected by flying bulk goods particles e.g. from injection pies, filling pipes or down pipes. Therefore the bulk solids stream should be directed or redirected accordingly, or the level indicator should be placed so that bulk solids cannot impact directly onto the probe and vibration rod.





Subject to modification