

## Vibro level indicators Level limit switches for bulk goods



MOLO



# **Explosion protection information**

and supplement to the operating instructions

Type plate det	ails with option B11 ઉલ્લઙ+Dust દિ×	
	Manufacturer and address CE sign with the number of the "Notified Body" which is involved in the production control phase EU-type examination certificate number	
	Industriepark RIO 103     Industriepark RIO 103     IBExU19ATEX1053X       Füllstandtechnik     Tel. +49 62 91 64 400     IP66/IP67     Type of protection	
Model designation ——— Unique device serial number	$\label{eq:constraint} \begin{array}{ c c c c c } \hline Typ & VF6.A1B11C5i & \hline & \hline & Ex \ ii \ 1/2 \ G \ Ex \ ia \ IIB \ T4 \ Ga/Gb \\ \hline & \hline$	age, and
Order number	Month and year of delivery GasEx identification Ambient temperature (process temperature) Design of the devices suitable for	





Vibro level indicator



## Marking in accordance with ATEX and DIN EN IEC 60079-0

Vibro level indicator for use at the boundary from zone 20 to zone 21.

	🐼 II 1/2 D Ex ia IIIC TX Da/Db			
Equivalent to	valid ATEX-Product-Directive			
Equipment group	II = everything except mining			
Equipment category	Category 1 for zone 20, 21 and 22			
<pre>/ = Level indicators which are instal</pre>	s, lled on the boundary between different zones			
Type of explosive at	mosphere D = Dust			
the Ex symbol acco	prding to DIN EN IEC 60079-0			
i = Protection by in	ntrinsic safety			
a = Device with "ve	bry high" protection standard for zone 20, 21 and 22			
<b>IIIC</b> for flammable of	conductive dust, flammable non-conductive dust and flammable fibres and flyings			
TX maximum surfa	ce temperature			
Equipment Protect	ion Level (EPL)			
D = Dust - Type of	f explosive atmosphere			
a = Device with "ve normal operation	ery high level of protection" for use in potentially explosive atmospheres where in			
b = Device with "high level of protection" for use in potentially explosive atmospheres where in				

#### Vibro level indicator for use at the boundary from zone 0 to zone 1.

😣 II 1/2 G Ex ia IIB T4 Ga/Gb	)			
Equipment category Category 1 for zone 0, 1 and 2 Category 2 for zone 1 and 2				
I = Level indicators, which are installed on the boundary between different zones				
Type of explosive atmosphere G = gas				
the Ex symbol according to DIN EN 60079-0				
i = Protection by intrinsic safety				
a = Device with "very high" protection standard for zone 0, 1 and 2				
IIB for all flammable gases except hydrogen, acetylene or carbon disulphide				
Temperature class T4 = 135 °C				
Equipment Protection Level (EPL)				
G = Gas - Type of explosive atmosphere				
a = Device with "very high level of protection" for use in potentially explosive atmospheres where in				
<b>b</b> = Device with "high level of protection" for use in potentially explosive atmospheres where in normal operation or foreseeable faults/malfunctions no ignition hazard is given.				

The "very high" protection standard of the devices permits although the use complete in zone 20 and zone 0. Please request further information if needed.



Vibro level indicator VF62/VF63



#### Order code VF62A1B11C5i... and VF63A1B11C5i...

Marking:

II 1/2 D



II 1/2 G

## Equipment category appropriation by

#### zones

Vibro level indicator for use at the boundary from zone 20 to zone 21 and for use at the boundary from zone 0 to zone 1.

#### **Ambient temperatures Ta**

The ambient temperature **Ta** defines the maximum operating temperature of the indicators. Inside the vessel this is process temperature (the air or the bulk goods temperature) nearby the device.

## Maximum surface temperature T, TX

The maximum surface temperature T means the hottest point at the equipment. The device equates to temperature class  $\boxed{T4}$ 

#### Note:

Probe and vibration rod produce no increase of temperature, but they are able to take high temperatures from inside of the vessel and forward it.

Due to this, the surface temperature **TX** has to be determined according to the process temperature (temperature of bulk solids or ambient) inside of the vessel.

#### Pressure, vacuum

Design of the devices is suitable for indicated pressures in the vessel. These pressures are outside of the range for atomospheric conditions defined in the guidance to the ATEX-Product-Directive.





maximum authorised process temperature

-20 °C ≤ Ta ≤ +80 °C/≤+60 °C maximum authorised ambient temperature at the electronic housing





#### Order code VF65A1B11C5i...

Marking: II 1/2 D II 1/2 G



## Equipment category appropriation by

#### zones

Vibro level indicator for use at the boundary from zone 20 to zone 21 and for use at the boundary from zone 0 to zone 1.

## **Ambient temperatures Ta**

The ambient temperature **Ta** defines the maximum operating temperature of the indicators. Inside the vessel this is process temperature (the air or the bulk goods temperature) nearby the device.

## Maximum surface temperature T, TX

The maximum surface temperature T means the hottest point at the equipment. The device equates to temperature class  $\boxed{14}$ 

#### Note:

Probe and vibration rod produce no increase of temperature, but they are able to take high temperatures from inside of the vessel and forward it. Due to this, the surface temperature **TX** has to be determined according to the process temperature (temperature of bulk solids or ambient) inside of the vessel.

#### Pressure, vacuum

Design of the devices is suitable for indicated pressures in the vessel. These pressures are outside of the range for atomospheric conditions defined in the guidance to the ATEX-Product-Directive.

	Industriepark RIO 103 D-74706 Osterburken Tel. +49 62 91 64 400	IBExU19ATEX1053X
тур <b>VF65A1<mark>B11</mark>G5i</b>	II 1/2D Ex ia IIIC TX Da/Db II 1/2G Ex ia IIB T4 Ga/Gb	Ui = 23,7 V DC Ii = 167 mA
s# <b>1234567890</b>	-20 °C ≤ Ta ≤ +70/+60 °C	Pi = <b>985 mW</b>
A Nr. 1234567890 03/1	9 (Process) -0,95bar+10,0bar	





Vibro level indicator VF62/VF63



Inside high process temperature, outside ambient temperature

## Order code VF62A1B11C5i...E1... and VF63A1B11C5i...E1...

Marking:

II 1/2 D II 1/2 G



## Equipment category appropriation by

#### zones

Vibro level indicator for use at the boundary from zone 20 to zone 21 and for use at the boundary from zone 0 to zone 1.

#### **Ambient temperatures Ta**

The ambient temperature **Ta** defines the maximum operating temperature of the indicators. Inside the vessel this is process temperature (the air or the bulk goods temperature) nearby the device.

## Maximum surface temperature T, TX

The maximum surface temperature T means the hottest point at the equipment. The device equates to temperature class T4

#### Note:

Probe and vibration rod produce no increase of temperature, but they are able to take high temperatures from inside of the vessel and forward it.

Due to this, the surface temperature **TX** has to be determined according to the process temperature (temperature of bulk solids or ambient) inside of the vessel.

#### Pressure, vacuum

Design of the devices is suitable for indicated pressures in the vessel.

These pressures are outside of the range for atomospheric conditions defined in the guidance to the ATEX-Product-Directive.

	Industriepark RIO 103 D-74706 Osterburken Tel. +49 62 91 64 400	1BExU19ATEX1053X       IBExU19ATEX1053X
тур VF6.А1 <mark>В11</mark> С5і <mark>Е1</mark>	Ex ia IIIC TX Da/ II 1/2G Ex ia IIB T4 Ga/	Db Gb Ui = 23,7 V DC Ii = 167 mA
S# 1234567890	-20°C ≤ Ta ≤ +150/+60°C	Pi = <b>985 mW</b>
A Nr. 1234567890 03/1	9 (Process) -0,95bar+10,0bar	Ci = neglig Li = neglig



maximum authorised process temperature

-20 °C  $\leq$  Ta  $\leq$  +150 °C/ $\leq$ +60 °C

maximum authorised ambient temperature at the electronic housing







## Special conditions and instructions for safe application

- 1. The installation, maintenance, initial operation, removal and repair have to be controlled resp. checked by an "authorized person" for explosion protection and has to be done according to the specifications in the operating instructions manual.
  - According to DIN EN 61010-1 a main switch for the supply and evaluation device has to be installed nearby and has to be made visible as such. It must be able to interrupt the power supply and relay circuit with this main switch.
  - For protection against surge voltages a overvoltage filter has to be installed accordingly.
- 2. For the electrical connection you have to take notice of the local and statutory requirements and/or the VDE 0100 as well as the additional requirements for the ignition protection type "i" intrinsic safety according EN 60079-14 for associated equipments without galvanic isolation.
  - The vibro level indicator is a category 1 equipment that has to be installed in such a way that sparks can not be generated by shocks onto or friction at the aluminium housing.
- 3. The power supply must be provided by the associated equipment "Supply and evaluation device VF-VEC8-B22" only.



- 4. Take notice of the specifications on the data plate.
- 5. Standards for the connection of intrinsic safe circuits according to EN 60079-14 must be observed.
- 6. The associated equipment "Supply and evaluation device VF-VEC8-B22" has to be installed in a room without potentially explosive atmosphere (control cabinet).
- 7. As soon as the device will be brought into the explosion hazardous area it has to be mounted immediately at the intended place and a cable has to be brought into the cable gland.
- 8. Please check if the cable gland have loosened during mounting process or transport. When it is loosened, it has to be fixed again with a torque of 3.75 Nm.
- 9. To secure the type of protection, the screw nut of the cable gland has to be fixed at the installation with a minimum torque of 2.7 Nm. ATTENTION! If it will be fastened too strong, the IP-protection can be affected.
- 10. The device has to be grounded and the ground connection of the device has to be installed in such a way that mechanical damage will be excluded.
- 11. The device may put into operation with built-in cap-sealing and when it is closed, only.
- 12. Remove the dust from the housing before you open it and make sure that no dust turbulences exist.
- 13. Please check position and intactness of all gaskets before you close the device.
- 14. Tightening torque of distance nut M6x40: 3 ... 4 Nm and of the lid screw M6x16: 3 Nm.
- 15. The maximum authorised temperatures for process (bulk solids) and ambience have to be observed.
- 16. Take notice of the requirements of DIN EN 60079-11, DIN EN 60079-17 and DIN EN 1127-1, especially regarding the dust deposits and temperatures and follow the pertinent rules and regulations.



Supply and evaluation device **VF-VEC8-B22** 



Type plate details



	Manufacturer and address	CE sign with the r which is involved	number of the "Notified Body" in the production control phase
Model designation	Füllstandtechniks VF-VEC8-B22	iepark RIO 103 6 Osterburken 9 62 91 64 400	EU-type examination certificate number
DustEx and GasExidentification	- II (1)G [Ex ia Ga] IIB II (1)D [Ex ia Da] IIIC	IBExU09ATEX1054X IP20	Type of protection
Ambient temperature	20 °C ≤ Ta ≤ +60 °C	Power Supply 20250 V DC/AC Power Consumption 3 VA	Details to power supply of the supply and evaluation device
(process temperature)	S# 1234567890     03/19       A Nr.     1234567890     Image: Comparison of		Details to intrinsic safety power supply of the Vibro level indivcator
	Month and year o	f delivery	
	Unique device serial r	number	
	Order number		





